

EPSON PAPIERE & FOLIEN: INK JET

EPSON papers & transparencies: ink jet



www.epson.de

Format, format

g/m²

Stärke, thickness (mm)

Blatt, sheets

Bestellnummer, order number

EPSON Stylus Color 460

EPSON Stylus Color 480

EPSON Stylus Color 580

EPSON Stylus Color 660

EPSON Stylus Color 670

EPSON Stylus Color 680/685

EPSON Stylus Color 760

EPSON Stylus Color 860

EPSON Stylus Color 880

EPSON Stylus Color 900

EPSON Stylus Color 980/N

EPSON Stylus Color C20UX/SX

EPSON Stylus Color C40UX/SX

EPSON Stylus Color C60

EPSON Stylus Color C70

EPSON Stylus Color C80

EPSON Stylus Photo 750

EPSON Stylus Photo 790

EPSON Stylus Photo 810

EPSON Stylus Photo 870/875DC

EPSON Stylus Photo 890/895

EPSON Stylus Photo 1270

EPSON Stylus Photo 1290

Premium Ink Jet Plain Paper

A4 80 250 S041214

Bright White Ink Jet Paper

A4 100 500 S041442

Photo Quality Ink Jet Paper

A6 144 50 S041054

A4 104 100 S041061

A4, Selbstklebend 167 10 S041106

Legal 105 100 S041067

Premium Glossy Photo Paper

A4 255 20 S041287

A3 255 20 S041315

A3+ 255 20 S041316

100 mm x 8 m 255 S041303

Photo Paper

A4 194 20 S041140

A3 194 20 S041142

A3+ 194 20 S041143

4" x 6" 194 20 S041134

21 cm x 59 cm 194 10 S041145

Sticker 16/A6 250 5 S041144

Sticker 4/A6 250 5 S041176

Karten 2" x 3,5" 194 10 S041177

100 x 150 mm 194 20 S041255

200 x 300 mm 194 10 S041254

329 mm x 10 m 194 S041233

Premium Semigloss Photo Paper

A4 251 20 S041332

A3 251 20 S041334

A3+ 251 20 S041328

100 mm x 8 m 251 S041330

210 mm x 10 m 251 S041336

329 mm x 10 m 251 S041338

Matte Paper – Heavyweight

A4 167 50 S041256

A3 167 50 S041261

A3+ 167 50 S041264

Ink Jet Transparencies

A4 0,124 30 S041063

Iron on Transfer Paper

A4 124 10 S041154

A3 124 5 S041238

Cards

A6 188 10 S041147

5" x 8" 188 10 S041148

8" x 10" 188 10 S041149

5" x 8" 188 30 S041121

8" x 10" 188 30 S041122

360 dpi Ink Jet Paper

A4 89 100 S041059

Photo Quality Ink Jet Glossy Film

A4 170 0,13 15 S041071

A6 170 0,13 10 S041107

Archival Matte Paper

A4 192 50 S041342

Color Life Photo Paper

A4 ??? 20 S041560

Double Sided Matte Paper

A4 178 50 S041569

MSEDG1123 Stand: Dezember 2001. Änderungen und Irrtümer vorbehalten.





Bestellnummer, order number	EPSON Stylus Color 460	EPSON Stylus Color 480	EPSON Stylus Color 580	EPSON Stylus Color 660	EPSON Stylus Color 670	EPSON Stylus Color 680/685	EPSON Stylus Color 760	EPSON Stylus Color 860	EPSON Stylus Color 880	EPSON Stylus Color 900	EPSON Stylus Color 980/N	EPSON Stylus Color 1160	EPSON Stylus Color 1520	EPSON Stylus Color C20	EPSON Stylus Color C40	EPSON Stylus Color C60	EPSON Stylus Color C70	EPSON Stylus Color C80	EPSON Stylus Photo 750	EPSON Stylus Photo 790	EPSON Stylus Photo 810	EPSON Stylus Photo 870/875DC	EPSON Stylus Photo 890/895	EPSON Stylus Photo 1270	EPSON Stylus Photo 1290
Verbrauch																									
Seiten, schwarz / pages, black	540	270	270	540	540	540	900	900	900	1200	1200	900	900	300	300	600	1240	1240	540	540	540	540	540	540	540
Farbabdeckung in %, duty per colour in %	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5	3,5
Seiten, farbig / pages, coloured	300	150	150	300	300	300	300	300	300	570	570	300	320	150	150	300	420	420	220	220	220	220	220	330	330
Farbabdeckung in %, duty per colour in %	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5
Tinten																									
Farbig / coloured	S020089																								
Schwarz / black	S020108																								
Schwarz / black	S020187	•			•	•														•					
Schwarz / black	S020189						•	•																	
Farbig / coloured	S020191	•			•	•	•	•																	
Farbig / coloured	S020193																			•					
Schwarz / black	T003011									•	•														
Schwarz / black	T007401																				•		•	•	•
Farbig / coloured	T008401																			•		•	•	•	•
Farbig / coloured	T009401																								•
Schwarz / black	T013401	•	•												•	•								•	•
Farbig / coloured	T014401	•	•												•	•									
Schwarz / black	T017401						•																		
Farbig / coloured	T018401						•																		
Schwarz / black	T019401								•																
Farbig / coloured	T020401								•																
Schwarz / black	T026401																					•			
Farbig / coloured	T027401																					•			
Schwarz / black	T028401															•									
Farbig / coloured	T029401															•									
Schwarz / black	T032140																		•	•					
Cyan	T032240																		•	•					
Magenta	T032340																		•	•					
Yellow	T032440																		•	•					
Farbig / coloured	T005011																								
2 x S020187	S020208	•	•			•	•	•												•					
2 x S020189	S020209						•	•				•													
2 x T003011	T003012									•	•														
2 x T007401	T007402																				•		•	•	•
2 x T013401	T013402	•	•												•	•									
2 x T019401	T019402								•																
2 x T017401	T017402						•																	•	•
1/2 x T007401	T010401																				•		•	•	•

Stand: Dezember 2001. Änderungen und Irrtümer vorbehalten.



COLOUR YOUR LIFE

EPSON[®]