

\$3& \$\div \\$3& 836 9\div 3\text{HGHVWD0}

Technical Data

\$3& 6PDUW 836 16 GLVWULEXWHG E\ +3

This product is targeted to user's who want to protect their servers and storage against downtime and data loss due to power anomalies. This product is part of HP's new pedestal UPS series and is available for use in Europe only.

The APC62A is available through Hewlett-Packard for customer orders.

) HDWXUHV

- Supplies network-grade battery backup when power fails
- Complete surge protection and noise filtering
- Low battery and overload indicator; battery replacement warning which prevents downtime
- Carries the APC logo, reminding network administrators that their server equipment is backed by the world's most reliable power protection.

6SHFLILFDWLRQV

- 9R0W \$PSV 620VA
- QSXW 9R0WDJH 230V
- 2XWSXW 5HFHSWDF0HV 4 IEC320-C13 (10 amps)
- 30XJ IEC320-C14
- : HLJKW 12.3 kg (27.06 lbs);
 w/pkg. 13.2 kg (29.04 lbs)
- &R0RU Quartz gray
- 3URGXFW' LPHQVLRQV +[: [' 168x119x368mm (6.72 x 4.76 x 14.72 in)
- 3DFNDJH ' LPHQVLRQV +[: [/ 318x622x1003mm (12.5 x 24.5 x 39.5 in)

, QVWD00DWLRQ

Tools required for installation:

- Phillips screwdriver
- : KDW \RX JHW LQ WKH ER[
- UPS
- PowerChute Plus software
- C14 attachment cap
- Serial communications cable
- Mounting rails and hardware
- Installation instructions

3URGXFW 1XPEHU \$3& \$



&RPSDWLELOLW\

This product is compatible with Netserver E800.

3UHYLRXV \$3& 3DUW 1XPEHU

■ SU6201NET

5H0DWHG 3URGXFWV

\$3& \$ - APC UPS 1000VA, pedestal

For additional product information, refer to the manufacturer's website: www.apcc.com

For additional rack solution product information, refer to the HP website: http://www.hp.com/racksolutions

: DUUDQW\

Warranty is provided solely through the manufacturer (APC). HP offers no warranty on this product.

6XSSRUW

Support is provided directly through the manufacturer (APC). Customers will call APC directly for any questions/issues with the product.

APC technical support is provided at no charge.

APC support numbers are listed in the product documentation. However, it can be also be found on the enclosures HP internal website:

http://enclosures.cup.hp.com